



CUSTOMER INFORMATION SHEET – NO. 024

CRUISEMASTER FITMENT CHECKLIST

The Check List below is a guide to assist with correct suspension installation and trouble free service.

For detailed installation information please refer to relevant installation drawing supplied with each suspension or available by contacting our sales staff.

WE STRONGLY ADVISE THAT MANUFACTURERS USE THIS CHECKLIST AND FILE SAFELY AWAY FOR FUTURE REFERENCE. WHERE THE MANUFACTURING PROCESS IS SPLIT BETWEEN CHASSIS AND VAN MANUFACTURER WE RECOMMEND BOTH PARTIES KEEP A COPY OF THE COMPLETED LIST.

Where responsibility for the below checks are shared between manufacturing parties this is done at the discrepancy of the parties involved and is not determined by vehicle components.

Date	Name	Vehicle ID
Hinge Bars - square on chassis, as per installation drawing		☐
Coil/Air Top Brackets - as per installation drawing		☐
Shock Absorber Bracket Support Plate - as per installation drawing		☐
Hinge Spindles Lubricated before fitment – Castrol heavy duty grease or equivalent		☐
Hinge Bush Ends Lubricated before fitment – Castrol heavy duty grease or equivalent		☐
Toe-In adjustment (Single - 2mm, Tandem - front axle 2mm, rear axle 0mm)		☐
Camber Adjustment – 0° to 0.5° negative camber (XT and ATX only)		☐
Hinge Bolts Torqued (XT – 190N.m, CRS – 190N.m, ATX – 190N.m, GT – 190N.m, X-CRUISE – 190N.m)		☐
Shock Absorber Bolts Torqued (XT – 120Nm, CRS2 – 50Nm, ATX – 120Nm, X-CRUISE – 50Nm)		☐
All bolts torqued as per installation documentation		☐
Hinges Lubricated – Pump grease through nipples until it starts coming out		☐
Check Brake Adjustment / Hydraulic Connections		☐
Fit CruiseMaster compliance plate in visible position		☐
Ensure CruiseMaster Owner's Manual is given to owner		☐
Solder and water proof brake wiring connections		☐